



1 SMART
Used to enter SMART mode, regardless if the unit is on or off. Temperature and fan speed are automatically set to room temperature for ideal comfort.

2 POWER
The unit will be turned on or off when pressed

3 SUPER
Used to start or stop the fast cooling. (Fast cooling operates at high fan speed with 16°C / 61°F set temperature automatically)

4 IFEEL
Used to set IFEEL mode operation. The temperature sensor on the remote control will be activated. It can sense its surrounding temperature and can adjust the temperature to provide ultimate comfort around the remote control.

5 SWING
Used to stop or start vertical louvered swinging position and set the desired up/down airflow direction.

6 CLOCK
Used to set the current time.

7 QUIET
Used to set or cancel Quiet Mode operation. In this mode, the air conditioner will work with low noise performance by low compressor frequency and low fan speed.

8 DIMMER
This button will turn off all the displays of indoor unit. Press any button to resume displays.

9 TEMP + -
Used to adjust the room temperature, timer, and clock.

10 MODE
Press this button to select the operation mode of cooling, dry, or fan only.

11 FAN
Used to select fan speed in sequence auto, high, medium or low.

12 SLEEP
Used to set or cancel Sleep Mode operation. This function gives more comfort for sleep.

13 SWING (OPTIONAL)
Used to stop or start Horizontal adjustment louver swinging and set the desired left/right airflow direction.

14 TIMER OFF
Used to set or cancel the timer operation.

15 ECONOMY
Used to set or cancel Economy Mode operation. This function will bring you energy saving performance by lowering the run time.

16 TIMER ON
Used to set or cancel the timer operation.



Indication symbols on LCD:

Cooling indicator	Auto fan speed	Sleep 1 indicator	Quiet indicator	Signal transmit
Dry indicator	High fan speed	Sleep 2 indicator	Smart indicator	Battery power indicator
Fan only indicator	Medium fan speed	Sleep 3 indicator	Economy indicator	ON 88:88 Display set timer
Heating indicator	Low fan speed	Sleep 4 indicator	Super indicator	OFF 88:88 Display current time
			Ifeel	88 °C Display temperature

Note: Each mode and relevant function will be further specified in following pages.